

# INSTALLATION MANUAL

## WELD-ON / PIVOT TUBE

### Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

### Weight Carrying Capacity

Refer to capacity listed on the product label

### Parts List

Item	Qty	Description
1	1	Jack
4	4	Weld-on pivot tube

### Tools Required

Weld machine	--
--------------	----

### NOTICE

Visit [www.curtmfg.com](http://www.curtmfg.com) for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

Periodic inspection of your product should be performed to ensure all hardware and / or components remain secure.

### Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: [curtmfg.com/registration](http://curtmfg.com/registration)

### ⚠ WARNING

Do not exceed the weight capacity or severe product damage, serious personal injury or death may occur. Keep people and pets at a safe distance during installation and operation of the trailer jack.

This installation may create a condition where severe product damage, serious personal injury or death may occur if stated precautions are not followed.

The trailer MUST be supported per the manufacturer's recommendations before working underneath. Failure to do so may result in death, serious personal injury or severe product or property damage.

### Product Photo



Actual product appearance will depend on part # purchased

### ⚠ CAUTION

Moving parts can pinch, crush or cut. Keep clear and use caution.

All welding must be performed by an AWS certified welder

### Step 1

Place the pivot tube against the frame of the trailer. Align one set of pivot mounting holes vertically.

Use a minimum 3/16" weld all-around the pivot tube.

Mount the jack to the pivot tube and secure using the supplied pin.

