



**ARIES OFFROAD
1042 GRAND CHEROKEE
1995-1998 4WD
INSTALLATION INSTRUCTIONS**

PARTS LIST

- 1 – Aries Front Bar**
- 1 – Mounting Bracket – Driver Side**
- 1 – Mounting Bracket – Passenger Side**
- 6 – 3/8” x 1 1/4” Hex Bolts**
- 12 – 3/8” USS Flat Washers**
- 6 – 3/8” Nylon Lock Nuts**

INSTALLING THE MOUNTING BRACKETS

Remove factory tow hooks from front section of vehicle (located within front bumper area). Using the bolts that held the tow hooks in place (there should be two of these bolts per hook). Attach the mounting brackets as per diagram below , do not fasten these bolts too tightly as you may have to move the brackets around slightly to align the grill guard to your vehicles front bumper – see next step installing the grill guard.

INSTALLING THE FRONT BAR

Line up the three holes on the lower portion of the front bar with the three holes in the mounting brackets (*outer edge*). Use the 3/8” hex bolts and the 3/8” lock nuts to fasten guard to the mounting brackets. Once the guard is attached to the brackets align guard to the bumper. Once you are satisfied that the grill guard is aligned. Begin to tighten all fasteners.

DIAGRAM. DRIVERS SIDE SHOWN

