

INSTALLATION INSTRUCTIONS AND PARTS LIST

APPLICATION: 570748 REAR STEP BRACKETS:

APPLICATION: 07+ SPRINTER VANS

1. READ INSTRUCTIONS COMPLETELY AND CHECK TO MAKE SURE THAT ALL REQUIRED PARTS (LISTED ON SERVICE PARTS LIST) ARE ON HAND BEFORE STARTING THE INSTALLATION.

NOTE: THIS WILL NOT FIT WITH THE FACTORY RECEIVER HITCH.

2. ON THE LEFT SIDE OF THE VEHICLE LOCATE THE MOUNTING HOLES ON THE REAR FRAME OF THE VEHICLE. USING FOUR (4) 7/16"-14 X 4" BOLTS (ITEM #4), FOUR (4) 7/16" FLAT WASHER (ITEM #5) AND FOUR(4) 7/16"-14 FLANGE NUTS (ITEM #6) INSTALL THE UPPER MOUNTING BRACKET (ITEM #1). TIGHTEN BOLTS TO 19 LB. FT.
3. USING FOUR (4) 3/8"-16 X 1" BOLTS (ITEM #7), FOUR (4) 3/8" FLAT WASHERS (ITEM #8) AND FOUR (4) 3/8"-16 FLANGE NUTS (ITEM #9) INSTALL THE LOWER MOUNTING BRACKET (ITEM #2). **NOTE: DO NOT TIGHTEN AT THIS TIME.**

NOTE: WHEN INSTALLING GRIP STEPS IT IS RECOMMENDED THAT THE LOWER BRACKET IS ALL THE WAY OUT AND MOUNTED IN THE LOWER SET OF HOLES, AND WHEN INSTALLING MEGA/O-MEGA STEPS THAT THE LOWER BRACKET IS SLID ALL THE WAY IN AND MOUNTED IN THE UPPER SET OF HOLES.

4. REPEAT STEPS 1 – 3 FOR THE RIGHT SIDE OF THE VEHICLE.
5. ATTACH THE STEP BOARD PER THE STEP BOARD INSTRUCTIONS. **NOTE: ONLY HAND TIGHTEN STEP BOARD BOLTS AT THIS TIME.**
6. ENSURE THAT THE STEP IS LEVEL AND POSITIONED CORRECTLY AND TIGHTEN ALL REMAINING BOLTS TO 19 LB. FT.

SERVICE PARTS LIST

ITEM	PART NO.	QTY	DESCRIPTION
1	552599	2	MOUNTING BRACKET – UPPER, 570748
2	552600	1	MOUNTING BRACKET – LOWER, RH, 570748
3	552601	1	MOUNTING BRACKET – LOWER, LH, 570748
4	103773	8	SCREW – HEX HEAD, 7/16"-14 X 4", ZP
5	100081	8	WASHER – FLAT , 7/16", ZP
6	103737	8	NUT – HEX, SERR FLANGE, 7/16"-14, ZP
7	100040	8	SCREW – HEX HEAD, 3/8"-16 X 1", ZP
8	100062	8	WASHER – FLAT, 3/8", ZP
9	100181	8	NUT – HEX, SERR FLANGE, 3/8"16, ZP



SERVICE PARTS LIST
 MODEL NO. - 570748

FIG. 1

