



# INSTALLATION MANUAL

## UTV-59KM

### Level of Difficulty

Easy

### Parts List

4	Bolt plate
8	Carriage bolt, 5/16" x 2"
8	Nylock nut, 5/16"
8	Flat washer, 5/16"

### Tools Required

Socket, 1/2"	Ratchet
Socket extension	

### Torque Specifications

	Metric	SAE	
	M6 bolt		3 ft.-lbs.
	M8 bolt		7 ft.-lbs.
	M10 bolt		16 ft.-lbs.
	M12 bolt		28 ft.-lbs.
	1/4" bolt		3 ft.-lbs.
	5/16" bolt		7 ft.-lbs.
	3/8" bolt		16 ft.-lbs.
	7/16" bolt		20 ft.-lbs.
	1/2" bolt		28 ft.-lbs.

Use above torque setting unless otherwise noted

### Product Photo



### UTV Tool box (not included)



### Notes and Maintenance

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

To protect the product, wax after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For polished, gloss and other smooth finishes, polish may be used to clear small scratches and scuffs on the finish.

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

Refer to the table to the left when securing hardware during the installation process to help prevent damage to the product or vehicle.

### Step 1

Place two carriage bolts into each bolt plate.

Slide the assembled bolt plates under the square tube on the UTV and turn upright.

Repeat this process for all four bolt plates.



### Step 2

If desired, place a piece of foam or tape (not included) on the square tube of the UTV between the toolbox and the square tube to protect the finish.

With assistance, carefully place the toolbox on the UTV.



### Step 3

Push the bolt plates with the carriage bolts into the slots on the toolbox.

While holding the bolt plate and carriage bolts in place, place two washers on each bolt.



### Step 4

Place the nuts on the carriage bolts and hand tighten.

Repeat for all eight carriage bolts.

Using a ratchet, snug all nuts, but do not fully tighten.



## Step 5

Adjust the toolbox to the desired position, making sure the carriage bolts are seated in the square holes of the bolt plates and that the lid of the toolbox can open freely.

Using a ratchet, fully tighten all hardware to the recommended torque specifications listed on page 1.

**CAUTION:** Do not over-tighten nuts. Damage to the UTV or toolbox may occur.



## Step 6

Congratulations on the installation of your new UWS UTV tool box.

With the tool box installed, periodic inspections should be performed to ensure all mounting hardware remains tight.

To protect your investment, see the 'Notes and Maintenance' section on the first page of this instruction manual.

If desired, tape (not included) can be placed over openings in the bottom of the toolbox to prevent dust from entering the toolbox in dusty conditions.

