



Double Lock EZr™ Application Guide

- No frame drilling required
- Some models may require lowering the exhaust
- Temporarily bend underbody flange for ease of installation

Double Lock EZr™ Installation Brackets (Rated to vehicle's max gross weight rating)

Make/Model	Style	Years From	Years To	Install Brackets#	EZr Hitch#	EZr Hitch with Install Brackets#
CHEVROLET						
Silverado 2500 HD	High Country	2015	2018	60624	60611	60680
	LT	2011	2018	60624	60611	60680
	LTZ	2011	2018	60624	60611	60680
	WT	2011	2018	60624	60611	60680
			2001	2010	60648	60619
Silverado 3500 HD	High Country	2015	2018	60624	60611	60680
	LT	2011	2018	60624	60611	60680
	LTZ	2011	2018	60624	60611	60680
	WT	2011	2018	60624	60611	60680
			2001	2010	60648	60619
DODGE						
Ram 2500		2003	2010	60660	60619	60682
Ram 3500		2003	2010	60660	60619	60682
FORD						
F-250		1999	1999	60647	60619	60685
F-250 Super Duty		2011	2016	60645	60619	60683
		1999	2010	60647	60619	60685
F-350 Super Duty		2011	2016	60645	60619	60683
		1999	2010	60647	60619	60685

GMC						
Sierra 2500 HD	Base	2015	2018	60624	60611	60680
	Denali	2011	2018	60624	60611	60680
	SLE	2011	2018	60624	60611	60680
	SLT	2011	2018	60624	60611	60680
	WT	2011	2014	60624	60611	60680
		2001	2010	60648	60619	60681
Sierra 3500 HD	Base	2015	2018	60624	60611	60680
	Denali	2011	2018	60624	60611	60680
	SLE	2011	2018	60624	60611	60680
	SLT	2011	2018	60624	60611	60680
	WT	2011	2014	60624	60611	60680
		2001	2010	60648	60619	60681
RAM						
2500		2011	2013	60660	60619	60682
3500		2011	2013	60660	60619	60682