

Grip Step™ XL 9-1/2" Van Running Board

Make / Model	Years	Kit # (Board and Brackets)	Board Only #	Brackets Only #	Conspicuity Tape Only #	Mount Type
Dodge						
Sprinter 2500	07 - 09	495154-401800	495154	401800	--	Rocker
		495154-401800-0	495154	401800	2090617	Rocker
Sprinter 3500	07 - 09	495154-401800	495154	401800	--	Rocker
		495154-401800-0	495154	401800	2090617	Rocker
Ford						
E-Transit	22 - 23	495154-401817	495154	401817	--	Rocker
Transit-150	17 - 25	495154-401801	495154	401801	--	Rocker
		495154-401801-0	495154	401801	2090617	Rocker
Transit-250	17 - 25	495154-401801	495154	401801	--	Rocker
		495154-401801-0	495154	401801	2090617	Rocker
Transit-350	17 - 25	495154-401801	495154	401801	--	Rocker
		495154-401801-0	495154	401801	2090617	Rocker
Freightliner						
Sprinter 2500	07 - 21	495154-401800	495154	401800	--	Rocker
		495154-401800-0	495154	401800	2090617	Rocker
Sprinter 3500	07 - 21	495154-401800	495154	401800	--	Rocker
		495154-401800-0	495154	401800	2090617	Rocker
Mercedes-Benz						
Sprinter 2500	10 - 25	495154-401800	495154	401800	--	Rocker
		495154-401800-0	495154	401800	2090617	Rocker
Sprinter 3500	10 - 25	495154-401800	495154	401800	--	Rocker
		495154-401800-0	495154	401800	2090617	Rocker
Ram						
ProMaster 1500	14 - 25	495154-401802	495154	401802	--	Rocker
		495154-401802-0	495154	401802	2090617	Rocker
ProMaster 2500	14 - 25	495154-401802	495154	401802	--	Rocker
		495154-401802-0	495154	401802	2090617	Rocker
ProMaster 3500	14 - 25	495154-401802	495154	401802	--	Rocker
		495154-401802-0	495154	401802	2090617	Rocker

Footnotes

*Continued while supplies last