

Impact™ Rear Bumper Steps

Make / Model	Years	Footnotes	Kit (Bumper and Bracket / Spring Assembly)	Bumper Only #	Brackets Only		Sensor Relocator #	Rubber Bumper Only #	Conspicuity Tape Only #
					Shock Absorbing #	Fixed #			
Dodge									
Sprinter 2500	07 - 09	2,3,4	415358-571500-0	415358	571500	--	571650	2090615-3	2090618
			415358-571500	415358	571500	--	--	--	--
			415358-571511	415358	--	571511	--	--	--
Sprinter 3500	07 - 09	2,3,4	415358-571500-0	415358	571500	--	571650	2090615-3	2090618
			415358-571500	415358	571500	--	--	--	--
			415358-571511	415358	--	571511	--	--	--
Ford									
E-Transit	22 - 24	--	415358-571501-0	415358	571501	--	571651	2090615-3	2090618
			415358-571501	415358	571501	--	--	--	--
Transit-150	15 - 25	1,2,3	415358-571501-0	415358	571501	--	571651	2090615-3	2090618
			415358-571501	415358	571501	--	--	--	--
			415358-571512	415358	--	571512	--	--	--
Transit-250	15 - 25	1,2,3	415358-571501-0	415358	571501	--	571651	2090615-3	2090618
			415358-571501	415358	571501	--	--	--	--
			415358-571512	415358	--	571512	--	--	--
Transit-350	15 - 25	1,2,3	415358-571501-0	415358	571501	--	571651	2090615-3	2090618
			415358-571501	415358	571501	--	--	--	--
			415358-571512	415358	--	571512	--	--	--
Freightliner									
Sprinter 2500	07 - 21	2,3,4	415358-571500-0	415358	571500	--	571650	2090615-3	2090618
			415358-571500	415358	571500	--	--	--	--
			415358-571511	415358	--	571511	--	--	--
Sprinter 3500	07 - 21	2,3,4	415358-571500-0	415358	571500	--	571650	2090615-3	2090618
			415358-571500	415358	571500	--	--	--	--
			415358-571511	415358	--	571511	--	--	--
Mercedes-Benz									
Sprinter 2500	10 - 25	2,3,4	415358-571500-0	415358	571500	--	571650	2090615-3	2090618
			415358-571500	415358	571500	--	--	--	--
			415358-571511	415358	--	571511	--	--	--
Sprinter 3500	10 - 25	2,3,4	415358-571500-0	415358	571500	--	571650	2090615-3	2090618
			415358-571500	415358	571500	--	--	--	--
			415358-571511	415358	--	571511	--	--	--
Ram									
ProMaster 1500	14 - 25	2,3	415358-571503-0	415358	571503	--	571652	2090615-3	2090618
			415358-571503	415358	571503	--	--	--	--
ProMaster 2500	14 - 25	2,3	415358-571503-0	415358	571503	--	571652	2090615-3	2090618
			415358-571503	415358	571503	--	--	--	--
ProMaster 3500	14 - 25	2,3	415358-571503-0	415358	571503	--	571652	2090615-3	2090618
			415358-571503	415358	571503	--	--	--	--
			415358-571513	415358	--	571513	--	--	--

Footnotes

- 1 - Remove factory bumper
 - 2 - Excluding factory receiver
 - 3 - May interfere with parking sensors
 - 4 - #571650 includes wiring harness
- *Continued while supplies last