

Grip Step™ Rear Step

Make / Model	Years	Kit # (See columns for included parts)	Boards Only #	Brackets Only #	Rubber Bumper Only #	Conspicuity Tape Only #
Chevrolet						
Express 1500	03 - 14	415254-400345	415254	400345	--	--
Express 2500	03 - 25	415254-400345	415254	400345	--	--
Express 3500	03 - 25	415254-400345	415254	400345	--	--
Dodge						
Sprinter 2500	07 - 09	415254-570749	415254	570749	--	--
	07 - 09	415254-570749-0	415254	570749	2090615-2	2090618
Sprinter 3500	07 - 09	415254-570749	415254	570749	--	--
	07 - 09	415254-570749-0	415254	570749	2090615-2	2090618
Ford						
E-Transit	22 - 24	415254-571528	415254	571528	--	--
Transit-150	15 - 25	415254-571528	415254	571528	--	--
Transit-250	15 - 25	415254-571528	415254	571528	--	--
Transit-350	15 - 25	415254-571528	415254	571528	--	--
Freightliner						
Sprinter 2500	07 - 21	415254-570749	415254	570749	--	--
	07 - 21	415254-570749-0	415254	570749	2090615-2	2090618
Sprinter 3500	07 - 21	415254-570749	415254	570749	--	--
	07 - 21	415254-570749-0	415254	570749	2090615-2	2090618
GMC						
Savana 1500	03 - 14	415254-400345	415254	400345	--	--
Savana 2500	03 - 25	415254-400345	415254	400345	--	--
Savana 3500	03 - 25	415254-400345	415254	400345	--	--
Mercedes-Benz						
Sprinter 2500	10 - 25	415254-570749	415254	570749	--	--
	10 - 25	415254-570749-0	415254	570749	2090615-2	2090618
Sprinter 3500	10 - 25	415254-570749	415254	570749	--	--
	10 - 25	415254-570749-0	415254	570749	2090615-2	2090618
Ram						
ProMaster 1500	14 - 25	415254-401478-0	415254	401478	2090615-2	2090618
	14 - 25	415254-401478	415254	401478	--	--
ProMaster 2500	14 - 25	415254-401478-0	415254	401478	2090615-2	2090618
	14 - 25	415254-401478	415254	401478	--	--
ProMaster 3500	14 - 25	415254-401478-0	415254	401478	2090615-2	2090618
	14 - 25	415254-401478	415254	401478	--	--

Footnotes

*Continued while supplies last