## 

# **INSTALLATION MANUAL**

### 13520

#### **Level of Difficulty**

#### Moderate

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Weight Carrying Capacity				
Gross trailer weight (GTW)	2,500 lbs.			
Tongue weight (TW)	250 lbs.			

#### Parts List

Item	Qty	Description
1	1	Trailer hitch
2	1	Mounting bracket, driver side
3	1	Mounting bracket, passenger side
4	6	Hex bolt, M12 x 1.25" x 35
5	6	Carriage bolt, 1/2"-13 x 1.25"
6	6	Conical-toothed washer, 1/2"
7	6	Serrated-flange nut, 1/2"-13

Too	ls	Req	uir	ed
	-			

Ratchet	Phillips screwdriver
Socket, 3/4"	Таре
Socket, 10mm	Tape measure
Socket, 19mm	Fishwire, 1/2" (includes 4 qty)
Torque wrench	Shears
Flathead screwdriver	
* For a tools reference quide visit	

curtmfg.com/trailer-hitch-installation

#### **△** WARNING

Never exceed the vehicle manufacturer's recommended towing capacity.

#### **Product Photo**



#### NOTICE

Visit www.curtmfg.com for a full-color copy of this

instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

This installation requires:

• Part removal and trimming of the underbody panel.

Periodic inspection of the trailer hitch should be performed to ensure all mounting hardware remains tight and structural components are secure.

To help prevent damage to the product or vehicle, refer to the specified

torque specifications when securing hardware during the installation process.

#### SAFETY INSTRUCTIONS


Safety glasses should be worn at all times while installing this product.


#### **Product Registration and Warranty**


CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: **warranty.curtgroup.com/surveys** 


# ASSEMBLY

Parts List		
Item	Qty	Description
1	1	Trailer hitch
2	1	Mounting bracket, driver side
3	1	Mounting bracket, passenger side
4	6	Hex bolt, M12 x 1.25" x 35
5	6	Carriage bolt, 1/2"-13 x 1.25"
6	6	Conical-toothed washer, 1/2"
7	6	Serrated-flange nut, 1/2"-13











Remove the rearmost lower bumper panel by removing 10 clips and set aside for reinstallation.


**Note:** Removing the large underbody panel may ease installation.





#### Step 2

Carefully dislodge the two electrical cables routed along the end of the driver-side frame rail.





#### Step 3

Loosely install the driver-side mounting bracket (#2) to the outside of the driverside frame rail using M12 hex bolts (#4) and conical-toothed washers (#6).


Repeat on the passenger side of the vehicle.





#### Step 4


Raise the hitch (#1) into position between the side plates installed in step 2. Secure with 1/2" carriage bolts (#5) installed from the center of the vehicle outward and serrated-flange nuts (#7). Use fishwires as needed to install bolts.



#### Step 5

Torque all M12 hardware to 86 ft-lbs. Torque all 1/2" hardware to 90 ft-lbs.

Trim the underbody removed in step 1 using the trim diagram for reference and reinstall.



#### **Final Installed Image**



#### **TOWING BASICS & SAFETY INFORMATION**

For information on safely towing your trailer, visit curtmfg.com/understanding-towing.

