

16301 DODGE '03 AND NEWER 2500 AND 3500

REFERENCE 16100 / 16200 INSTRUCTION SHEETS FOR PROPER INSTALLATION OF 16301 BRACKET KIT.

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1/2"	FISHWIRE TOOL
2	4	CM-SP27	.188 x 1.00 x 2.00" U-SHAPE SPACER
3	2	CM-SP53	.250 x 1.50 x 3.00" SQUARE HOLE SPACER
4	2	1/2 - 13 x 2"	CARRIAGE BOLT
5	2	1/2"	LOCK WASHER
6	2	1/2"	WASHER
7	2	1/2-13	HEX NUT
8	1	CM-16301-DS	.375" DRIVER SIDE PLATE
9	1	CM-16301-PS	.375" PASSENGER SIDE PLATE

