

INSTALLATION MANUAL

18425

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Weight Carrying Capacity

Load capacity 50 lbs.

Parts List

Item	Qty	Description
1	1	Tray
2	1	Left Upright
3	1	Right Upright
4	2	Frame Bar
5	1	Middle Seat Strap
6	2	Headrest Strap
7	2	Ladder Lock
8	1	Strap Cover

Product Photo



NOTICE

Visit www.curtmfg.com for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

Periodic inspection of your product should be performed to ensure all hardware and / or components remain secure.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: warranty.curtgroup.com/surveys

ASSEMBLY

Parts List

Item	Qty	Description
1	1	Tray
2	1	Left Upright
3	1	Right Upright
4	2	Frame Bar
5	1	Middle Seat Strap
6	2	Headrest Strap
7	2	Ladder Lock
8	1	Strap Cover



FRAME ASSEMBLY

Step 1

Thread the side marked 'TOP' of the middle seat strap around one of the frame bars.

Ensure the ladder buckle is toward the back so it will end up over the middle seat. Slide the strap to the center of the bar.



Step 2

Thread one of the head rest straps onto one side of the same frame bar.

Repeat with the second headrest strap on the other side of the frame bar.



Step 3

Thread the other side of the middle seat strap to the center of the second frame bar.

Disconnect the bottom of the middle seat strap from the top.



Step 4

Connect the left upright to the top and bottom bar. Ensure the preinstalled strap is in the front of the frame and up by the headrest strap.

Repeat on the right side.



CARGO CADDIE INSTALLATION

Step 1

Buckle one of the head rest straps to the corresponding headrest. Repeat on the other side.

Tighten the headrest straps so that the top of the frame is positioned at the top of the seat back.



Step 2

Thread the bottom of the middle seat strap behind the middle seatback. Pull the bottom strap through to the front of the seat. The strap will be between the seat back and base.



Step 3

Connect the bottom strap to the top strap using the ladder buckle. Place the strap cover over the strap to protect the top of the seat. Tighten strap so the frame is snug against the back seat.



Step 4

Insert the tray into the desired position by angling the tray and sliding the sockets on the tray over the mounting pins on the frame. Once inserted on both sides, push the tray down so it is locked into place.



Step 5

Place a ladder lock onto each of the side straps. Thread each of the side straps through the corresponding cam buckle. Adjust the side straps so the tray is level. Thread any excess strap through the ladder lock



Step 6

Secure the tray belt to the bottom strap. Tighten as necessary.



STOWING CARGO CADDIE

Step 1

The tray must be in the lower position to be stowed. If the tray is in the higher position, slightly lift the tray and pull to remove.

Close the tray and connect the tray belt to the top buckle if desired. Tighten as necessary.

