


**31322****CHEVY SILVERADO****7/30/2020**

**GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 5,000 LBS. TRAILER WEIGHT & 500 LBS. TONGUE WEIGHT.**  
**GROSS LOAD CAPACITY WHEN USED AS A STRAIGHT LINE PULL: 9,000 LBS. MAX. LINE PULL.**  
**\*\*\* DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY. \*\*\***  
**HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-877-287-8634**

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1_2 FISHWIRE	1/2" FISHWIRE
2	1	10-10272	BOLT,CAR,1/2-13 UNC,1-3/4,GRD8,YZ
3	1	CM-SP1	.250 x 1.50 x 2.00" SQUARE HOLE SPACER
4	8	30-00133	WASHER,FLAT,1/2,YZ
5	1	20-00062	NUT, SER-FLANGE,1/2-13 UNC,GRD8,YZ
6	8	10-10311	BOLT,CAR,7/16-14 UNC,1,GRD8,YZ
7	8	20-00103	NUT,SER-FLANGE,7/16-14 UNC,GRD8,YZ
8	1	CM-31322-SP	11GA. A-36 H.R. OVAL SPACER

TOOLS REQUIRED
SOCKET WRENCH
10 MM SOCKET
17 MM SOCKET
18 MM SOCKET
19 MM SOCKET
21 MM SOCKET
18 MM WRENCH
TORQUE WRENCH



**HITCH WEIGHT:** 35 LBS.

**INSTALL TIME**

PROFESSIONAL: 30 MINUTES

NOVICE (DIY): 60 MINUTES

**INSTALL NOTES:**

- NO DRILLING REQUIRED

- FISHWIRE HARWARE

**INSTALLATION STEPS - REMOVE AIR DAM IF PRESENT-**

- 1) Fasten driver and passenger side plates to corresponding frame rails with existing hardware. Ensure that plates are installed loosely to provide adjustment for future installation steps.
- 2) Install cross member between plates and secure with hardware provided.(Trim fascia as needed.)
- 3) Fishwire 1/2" carriage bolt and spacer through frame. Insert small oval spacer into hole in frame. Secure main body strap using hardware provided.
- 4) Torque all 7/16" hardware to 70 lb-ft. and all 1/2" hardware to 110 lb-ft. Torque all M12-1.75 to 79 lb-ft. and all M14-2.0 to 126 lb-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.

**\*\*\*DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY \*\*\*.**

### FRONT MOUNTED ACCESSORIES

1) Do not exceed front axle Gross Weight Rating (GAWR). Consult owners manual or specification plate located on driver's door frame. Measure gross front axle weight by placing front wheels of loaded vehicle on a scale.

**WARNING:** Exceeding GAWR may overload the front axle and/or suspension. This could result in **accident, property damage and personal injury.**

- 2) Reposition front mounted license plate if obstructed.
- 3) Do not obstruct vehicle lights.
- 4) Allow free air flow into grille opening.
- 5) Rear wheel traction may be reduced. This could effect handling. Reduce speed and drive with caution.
- 6) Accessories extend front of vehicle. This may reduce approach angle. Use caution when parking and maneuvering.
- 7) Do not obstruct driver view.


### VEHICLE RECOVERY AND WINCHING TIPS

1) Use OEM tow hooks, recovery eyes or a clevis mount for attachment of a tow strap or winch cable.

**WARNING: NEVER** use a ball and/or ball mount as an anchor point for tow strap or winch cable. Severe personal injury or death could result.

- 2) Observe winch manufacturer's recommendations, cautions and warnings.
- 3) Attach return cable to tow hook or recovery eye when using a snatch block (See figure 1).

**CAUTION:** Do not attach return cable to winch mount. This may overload winch mount and/or front mounted receiver.



### RATING

For **Maximum** line pull rating, winch cable must not exceed:

- 15 degree angle up or down from horizontal (See Figure 2).
- 45 degree angle left or right from straight ahead (See Figure 3).

**CAUTION:** Exceeding the maximum line pull rating may over load winch, winch mount, and/or front mounted receiver.

