



INSTALLATION MANUAL

51534

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Wiring Location(s)

Under dash, near driver-side kick panel

Tools Required

Ratchet	Panel trim removal tool
Torx bit, T15	

* For a tools reference guide visit curtmfg.com/trailer-hitch-installation

Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: warranty.curtgroup.com/surveys

⚠ WARNING

Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Be sure not to lay tools across the positive terminal (typically noted with red covers or a red '+' symbol). This can cause a ground to short leading to sparks and/or electrical shocks.

Product Photo



NOTICE

Visit www.curtmfg.com for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

All steps must be followed to ensure the product will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

Step 1

Ensure the vehicle ignition is off and not in the "ON" or "ACCESSORY" positions prior to installation.

NOTICE

Plug the brake control adapter into the mating connector on the brake controller prior to attaching to the vehicle connectors. Make sure the connectors are attached with all locking tabs in place.

Step 2

Carefully pull down the cover underneath the dash with a panel trim removal tool.

Use a T-15 Torx bit to remove the screws from retaining the panel.



Step 3

Use a panel trim removal tool to carefully pull back the driver-side sill plate and kick the panel to expose the green 4-pin brake control harness connector. Install the custom brake control harness to the factory harness and make sure the connectors are inserted all the way with the locking tabs in place.



Step 4

Follow the brake controller manual for installation and set-up instructions.

After testing the harness and controller, replace all parts removed in reverse order of steps 1-3.