55774

BUICK ENCLAVE BUICK RAINIER CADILLAC ESCALADE CHEVY AVALANCHE CHEVY SILVERADO CHEVY SUBURBAN CHEVY TAHOE CHEVY TRAILBLAZER GMC ACADIA GMC ENVOY

GMC SIERRA GMC YUKON HUMMER H2 & H3 INFINITI QX56 ISUZU ASCENDER NISSAN PATHFINDER NISSAN TITAN OLDSMOBILE BRAVADA SAAB 9-7X SATURN OUTLOOK

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

IDEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filetée.

04/10/07





English

For Vehicles without a Factory 7-Way:
1. Locate the tow vehicle's trailer harness connector. This harness is located under the vehicle, behind the bumper, on the driver's side of the vehicle.T3

- 2. Remove protective cap (and save) from connector; check to see that the mating surfaces of the connectors are free or dirt. Clean if necessary.
- 3. Connect the T-connector adapter end to the vehicle's connector (A). Be sure that the T-connector is fully inserted with locking tabs in place.
- 4. Place protective cap on remaining plug end. Skip to step 7 for remaining installation instructions.

For Vehicles with a Factory 7-Way: 5. Locate the Factory 7-Way attached to the hitch on the driver's side.

- 6. Separate the factory socket and 7-Way.
- 7. Plug the T-Connector between the Factory socket and 7-Way.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

