

INSTALLATION MANUAL

52208

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit:

warranty.curtgroup.com/surveys

WARNING

Avoid distracted driving. Only make adjustments when the vehicle is stationary. Please adhere to all applicable traffic laws and motor vehicle safety regulations including, but not limited to, all laws and regulations prohibiting the use of handheld devices while operating a motor vehicle.

Product Photo



COMPONENTS

Parts List

Item	Qty	Description
1	1	Command center tablet
2	1	Command center hub
3	1	Tablet dash mount
4	1	Hub wall mount
5	2	3' micro USB cable
6	2	Dual USB chargers

NOTICE

Visit www.curtmfg.com for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.



SETUP

TABLET

Step 1

The dash mount for the tablet can be mounted to glass or plastic. Before mounting, clean surface of dust and debris.

1. Peel protective cover from 3M gel suction cup and press firmly in your preferred location.
2. Snap down the suction lock lever.
3. Adjust the magnet surface in the direction of choice and tighten the threaded knob securely.




If 3M gel suction cup loses its stickiness, rinse with warm water and let air dry.

NOTICE

Textured surfaces are not recommended for mounting.

Step 2

To power on the tablet, press and hold the single power button for 3 seconds. Charging the tablet with the provided USB cable and 12V USB charger may be necessary if the battery is low or dead. A fully charged battery lasts about three hours.




HUB

Step 1

Thread the antenna onto the hub so that the antenna points up 90° towards the face of the hub.


NOTICE

Though it is not required, the most optimal position for the antenna is to point straight up in the air.



Step 2

The wall mount for the hub can be mounted to wood or plastic. Mount as close as possible to the center of the RV, near a 12V outlet for powering the hub. For class A motorhomes, it is recommended to mount towards the rear of the coach on a side exterior wall inside the RV. Before mounting, clean surface of dust and debris. Peel paper cling from the back of the wall mount and press firmly to surface for best attachment.



NOTICE

Textured surfaces are not recommended for mounting.


Step 3

To power on the hub, press the power button. If the blue LED does not illuminate, then the battery needs to be charged. Use the provided USB cable and charger. The hub has an internal battery, but it is recommended to leave the hub plugged in at all times. To power off the hub, press and hold the power button for three seconds.

The hub has two LEDs: a power LED and a blue blinking LED. The power LED has four states:

- No light: Not charging.
- Solid red: Not charging and battery below 25%.
- Pulsing green: Battery charging.
- Solid green: Fully charged battery.

The blue blinking LED indicates that the hub is powered on and will automatically connect to the tablet once the tablet is powered on.



OPERATION

TABLET DASHBOARD


Introduction

When you first power on the Command Center tablet, it will connect to the hub. The Dashboard will appear on the screen. The Dashboard comes loaded with the following Command Center apps and has the ability to display official Command Center products as they are added.

Drive Mode

The Drive Mode app is for monitoring, controlling, and operating the products that you have as you're traveling (i.e. RVBrake3 and Tire Patrol). Drive Mode products need to be enabled in the Add Device app before they will appear in Drive Mode.

If you are monitoring more than one product in Drive Mode, you can select the different product icons in the Dock to view them.



The Dock also gives quick access to information about the status of the Command Center tablet and hub.

Command Center
Hub connection —
status
(yellow is connected, grey is disconnected)



Tablet battery
status

Low level warning
reminder
*(grey means everything is good,
red indicates ongoing issue)*

RV Level App

The RV Level app works with the hub to allow you to level your RV. To level the RV:

1. Unplug the hub and place it on a flat surface on the floor in the middle of the RV.
2. Point the triangle "F" towards the front of the RV.
3. The RV Level app will give instructions on which side of the RV needs to be raised until the RV is level on all four sides.

If the jacks are fully extended but the RV is not level, retract all jacks and repeat the leveling process.



RV Level

Checklist App

The Checklist app is a tool for keeping track of pre-trip tasks, making it easy to edit and add items. The Checklist comes with three categories: "Getting Ready for Takeoff", "Setting Up Camp", and "Breaking Camp".

To add a to-do item to a category, select "+ New". You can choose to create either a Single- or Multi-step to-do item. To edit a name or remove an item from the list, select "Edit". Selecting the "pencil" icon will allow you to edit a title, while selecting the red "x" will delete the item.

After you have checked everything off your list, select the "Uncheck Boxes" button before your next trip to clear all checked boxes.



Travel Checklist

Support App

The Support app contains general information, FAQs, troubleshooting, and contact information for customer support.



Support

Add Device App

The Add Device app is your dashboard shortcut to pairing a new official Command Center product. Simply tap the ON/OFF switch of a new product to enable it.



Add Device

Settings App

The Settings app is a multi-layered app. Here, you can add official Command Center products, download product updates, edit the settings of the tablet, and more. The Settings app contains the following sections:



Settings

Products: Newly purchased official Command Center products are enabled here. Until a product is enabled, it will not show on the tablet dashboard.



Command Center: Check to see if the Command Center hub is paired and connected, and how much battery life it has left. The RV Level can also be calibrated here.



NOTICE

Calibration should not be done unless instructed by customer support.

Tutorials: Each product and its associated app has a tutorial, and each one can be viewed here.



Display: Set the screen brightness level. Drive Mode orientation can also be adjusted here.



Profile: Here is where you can register your tablet for warranty.



Software update: Any updates to the tablet can be done here. The tablet will walk you through connecting to the internet and updating. When updates for the tablet are released, RVI will send notification emails to let users know.



NOTICE

For security reasons, only connect the tablet to password-secured Wi-Fi networks.

COMPLIANCE

Antenna Useage

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. FCC Radiation Exposure Statement to comply with FCC RV exposure requirements in section 1.1307, a minimum separation distance of 0.81 cm (0.3 inches) is required between the antenna and all persons. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

FCC ID:Z64-CC3100MODR FCC ID: RVi-CC3P0

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiver antenna.

Increase the separation between the equipment and the receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

The Installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RV field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's website <http://www.hc-sc.gc.ca/rpb>

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement

NOTICE

Changes or modifications not expressly approved by CURT Manufacturing LLC could void the user's authority to operate the equipment.

WARRANTY

Limited Warranty

How long is the warranty?

Command Center tablet and hub have a one year limited warranty from the original purchase date.

What is covered?

It warrants your product to be free of mechanical and electrical defects in material and workmanship.

Where or how do I get assistance for my RVi product?

During the warranty period, RVi will repair or replace the product (at RVi's discretion), which will be your exclusive solution under this warranty.

Do NOT return the product, doing so may delay the processing of your claim and the repair or replacement of the product. For return instructions, please call RVi Customer Service.

What is not covered?

The warranty will not cover damage resulting from neglect or misuse of the product, use contrary to operating instructions, or disassembly, repair, or alteration by any person other than RVi's repair department. RVi is not liable for any incidental or consequential damages for breach of any expressed or implied warranty on the product.

How state laws may apply

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation may NOT apply. This warranty gives specific legal rights, and you may also have other rights, which vary from state to state.

"This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."