

11092**KIA RIO 5 / HYUNDAI ACCENT HATCHBACK**

10/22/2020

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.

*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.*****

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.

**** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY****



HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 877-287-8634

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	10-10275	HHCS,M12x1.25,35,CL10.9,YZ
2	1	10-10287	BOLT,CAR,1/2-13 UNC,1-1/2,GRD8,YZ
3	1	10-10272	BOLT,CAR,1/2-13 UNC,1-3/4,GRD8,YZ
4	1	CM-SP40	.188 x 1.00 x 3.00" SQUARE HOLE SPACER
5	1	CM-SP34	.188 x 1.50 x 3.00" ROUND HOLE SPACER
6	2	30-00149	WASHER,S-CON,1/2,YZ
7	2	20-00062	NUT, SER-FLANGE,1/2-13 UNC,GRD8,YZ
8	1	1_2 FISHWIRE	1/2" FISHWIRE

FISHWIRE TECHNIQUE

INSERT COILED END OF FISHWIRE TOOL THROUGH HITCH MOUNTING HOLE IN VEHICLE FRAME RAIL AND OUT THE ACCESS HOLE. PASS COILED END OF FISHWIRE THROUGH SPACER AND THREAD BOLT INTO COIL. KINK WIRE TO KEEP SPACER SEPERATE FROM BOLT AS SHOWN. PULL FISHWIRE, SPACER, AND BOLT THROUGH FRAME AND OUT MOUNTING HOLE. USE FISHWIRE TO GUIDE HITCH DURING MOUNTING AND PREVENT LOSS OF BOLT / SPACER INSIDE FRAME RAIL.

****NOTE: SOME VEHICLES MAY FISHWIRE THROUGH END OF FRAME****



HITCH WEIGHT: 27 LBS.

INSTALL TIME

PROFESSIONAL: 45 MINUTES

NOVICE (DIY): 90 MINUTES

INSTALL NOTES:

- HOLE ENLARGEMENT
- FISHWIRE HARDWARE

INSTALLATION STEPS

1. Lower exhaust for ease of installation.
2. Remove heat shield and cut out corner nearest to hole which gets enlarged, then reattach heat shield.
3. Raise hitch into position, and place 1/2" carriage bolt into safety chain plate above vehicle's tow loop and fasten finger tight with 1/2" flange nut and CM-SP34 spacer as shown.
4. Fasten two M12 bolts with 1/2" conical tooth washers to existing weldnuts in driver side frame rail finger tight as shown.
5. Enlarge hole in passenger side frame rail to fit 1/2" bolt.
6. Fishwire 1/2" carriage bolt with CM-SP40 spacer through passenger side frame rail from edge of bumper to enlarged hole. Fasten finger tight with 1/2" flange nut.
7. Torque all 1/2" hardware to 110 ft-lbs, and all M12 hardware to 86 ft-lbs.
8. Reattach exhaust to hanger locations removed in Step 1.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.