



# INSTALLATION MANUAL

## 003-CBOXMK

### Level of Difficulty

Easy

### Parts List

2	Flange bolt, M8
2	Flat washer, 5/16" rubber bonded
2	Turn nut, M8

### Tools Required

Wrench set	Drill bit, 1/2"
Drill	--

### Torque Specifications


M6 bolt	3 ft-lbs.
M8 bolt	7 ft-lbs.
M10 bolt	16 ft-lbs.
M12 bolt	28 ft-lbs.

Use above torque setting unless otherwise noted

### ⚠ WARNING

Before drilling into your truck bed, refer to the installation manual included with your UWS tool box for all notices, cautions and warnings.

### Product Photo



### Notes and Maintenance

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

Refer to the table to the left when securing hardware during the installation process to help prevent damage to the product or vehicle.

### Product Registration

CURT Group stands behind our products with industry leading warranties. You can help us continue to improve our product line and help us understand your needs by registering your purchase by visiting:

[warranty.curtgroup.com/surveys](http://warranty.curtgroup.com/surveys)

At CURT Group, customer is king. We value your feedback and we use that information to make improvements on our products. Please, take a minute and let us know how we are doing.

### Step 1

Align your UWS tool box to a desired location in the bed of your truck. Drill a 1/2" hole in the desired location. Insert a turn nut into the drilled hole.



### Step 2

Place a bonded flat washer onto a flange bolt and gently push the bolt into the turn nut.

Once the turn nut rotates, insert the flange bolt into the turn nut and tighten to the torque values specified on the first page of this manual.

**Note:** Cross sections shown are for reference only. Fasteners will be used to secure the tool box to the bed of a truck.

With the tool box installed, periodic inspections should be performed to ensure all mounting hardware remains tight.

