

11039

00-02 PLYMOUTH NEON & 00-05 DODGE NEON

10/5/2012

(EXCEPT R/T, ACR, SRT-4 & MAGNUM)

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.


** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813


| Parts List | | | | |
|------------|-----|----------------|--|--|
| ITEM | QTY | PART NUMBER | DESCRIPTION | |
| 1 | 4 | 1/2-13 x 1 3/4 | CARRIAGE BOLT | |
| 2 | 2 | CM-SP40 | .188 x 1.00 x 3.00" SQUARE HOLE SPACER | |
| 3 | 4 | HFN 1213 | HEX FLANGE NUT | |
| 4 | 2 | CM-SP113 | .188 x 1.25 x 1.25 SPACER | |
| 5 | 1 | 1/2" | FISHWIRE TOOL | |

FISHWIRE TECHNIQUE

INSERT COILED END OF FISHWIRE TOOL THROUGH HITCH MOUNTING HOLE IN VEHICLE FRAME RAIL AND OUT THE ACCESS HOLE. PASS COILED END OF FISHWIRE THROUGH SPACER AND THREAD BOLT INTO COIL. KINK WIRE TO KEEP SPACER SEPARATE FROM BOLT AS SHOWN. PULL FISHWIRE, SPACER, AND BOLT THROUGH FRAME AND OUT MOUNTING HOLE. USE FISHWIRE TO GUIDE HITCH DURING MOUNTING AND PREVENT LOSS OF BOLT / SPACER INSIDE FRAME RAIL.



NOTE: SOME VEHICLES MAY FISHWIRE THROUGH END OF FRAME



HITCH WEIGHT: 23 LBS.

INSTALL TIME

PROFESSIONAL: 10 MINUTES

NOVICE (DIY): 20 MINUTES

INSTALL NOTES:

- NO DRILLING REQUIRED
- FISHWIRE HARDWARE

INSTALLATION STEPS

1. Fishwire a 1/2" carriage bolt and CM-SP113 spacer into the rearmost round hole in each frame rail using the oval access hole. Fishwire a 1/2" carriage bolt and CM-SP40 square hole spacer into the oval hole in each frame using the oval access hole. (See Fishwire Technique.)
2. Raise the hitch into position against the frame rails, aligning the fishwired hardware with the slots in the hitch side plates. Secure the hitch to the vehicle using (4) hex flange nuts as shown. (Take care not to push the fishwired hardware into frame rails.)
3. Torque all hardware to 110 ft-lbs.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.

24678/ 247367