

INSTALLATION MANUAL

13640

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Weight Carrying Capacity

Gross trailer weight (GTW)	3,500 lbs.
Tongue weight (TW)	525lbs.

Parts List

Item	Qty	Description
1	1	Trailer hitch
2	2	Mounting Spacer
3	6	Hex bolt, M12 – 1.25 x 65mm, CL 8.8
4	6	Conical-toothed washer, 1/2"

Tools Required

Ratchet	Socket, 19mm
Torque wrench	Flathead screwdriver

* For a tools reference guide visit curtmfg.com/trailer-hitch-installation

⚠ WARNING

Never exceed the vehicle manufacturer's recommended towing capacity.

Product Photo



NOTICE

Visit www.curtmfg.com for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

This installation requires:

- Temporary lowering of the exhaust

Periodic inspection of the trailer hitch should be performed to ensure all mounting hardware remains tight and structural components are secure.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

SAFETY INSTRUCTIONS

Safety glasses should be worn at all times while installing this product.





Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: warranty.curtgroup.com/surveys

ASSEMBLY

Parts List

Item	Qty	Description
1	1	Trailer hitch
2	2	Mounting Spacer
3	6	Hex bolt, M12 – 1.25 x 65mm, CL 8.8
4	6	Conical-toothed washer, 1/2"



Step 1

Lower the exhaust by removing the two rear-most exhaust hanger rods on both sides from the two rubber isolators.


Note: Use a stand to support the exhaust and prevent any damage.



Step 2

If present, remove stickers covering the three weld nuts on the outside of both frame rails.

Note: Temporarily insert M12 (#3) bolts into the frame weldnuts to ensure the threads are free from debris. Clean threads if needed.



Step 3

Position the hitch side plates between the exhaust and rear fascia cover.

Rotate the plates over the exhaust and lift into position.



Step 4

Starting on the driver's side, slide a mount spacer (#2) between the hitch and frame rail with its tang pointing towards the front of the vehicle.


Aligning the hitch mounting holes and mount spacer holes with the frame weld nuts, loosely install the M12 bolts (#3) and conical washers (#4).

Repeat for the passenger side.



Step 5

Torque M12 hardware to 68 ft-lbs.



Step 6

Raise the exhaust back into position and reinstall the two rubber isolators.



Final Installed Image



TOWING BASICS & SAFETY INFORMATION

For information on safely towing your trailer, visit curtmfg.com/understanding-towing.