

INSTALLATION MANUAL

25015

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Parts List			
Item	Qty	Description	
1	1	Jack handle	
2	1	Retaining pin, 4mm	
3	1	Retaining pin, 5mm	
4	1	Drill bit, 5mm	

Tools Required			
Ratchet	Socket set		
Drill			

Product Registration

CURT stands behind our products with industry-leading warranties. Provide feedback and help us to improve our products by registering your purchase at: warranty.curtgroup.com/surveys

⚠ WARNING

Do not expose hands, body parts or clothing anywhere between the truck and trailer. Extreme care should be observed to avoid serious injury to self, property and observers.

Product Photo



NOTICE

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

Maintenance

To protect the product, wax after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

Step 1

Remove the top cover of the jack to expose the jack gear. Wipe away any excess grease.

Use a hammer and punch to remove the original retaining pin and handle. Measure the original pin to determine the correct pin size to use.

Insert the new handle through the jack housing and gear. Align the gear pin hole and handle pin and insert either the 4 mm or 5 mm pin.

To install the 5 mm pin, use the provided 5mm drill bit to enlarge the handle pin hole.

Add grease to the jack gears and reinstall the cover.

