

55367

TOYOTA TUNDRA

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement fileté.

7/13/10



English

1. Locate the vehicle's factory tow harness location (T4). The harness will have connectors similar to the one on the T-connector harness. Remove the protective cap being sure not to damage the locking tabs. Insert the harness connector into the vehicles tow harness connector. Make sure the connectors are fully inserted with locking tabs in place.

2. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location. Secure any loose wires with the cable ties provided.

3. Connect the ring terminal to the vehicle's positive battery terminal. On the driver side of the engine compartment locate the vehicle's power wire connector. The connector will have connection points matching the power wire connector. Insert the connector making sure the connectors are fully inserted with locking tabs in place. Insert the 10 AMP fuse into the fuse holder. Secure any loose wires with the cable ties provided. Make sure to avoid any areas that may cut or pinch the wires.



55367