

55413

CHEVROLET S-10 BLAZER
GMC S-15 JIMMY

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

English

1. Open the rear vehicle hatch and remove the tread plate along the floor line.
2. Remove the left (Drivers) side trim panel to expose the jack storage area. Temporarily the vehicle jack.
3. Locate the vehicle tail light wiring harness. The harness will have connectors similar to those on the T-Connector harness.
4. Carefully separate the vehicles connectors and check for dust, dirt or debris. Clean if necessary.
5. Position the T-connector ends between the separated vehicle harness connectors and firmly press together, ensuring that the locking tabs engage.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage to vehicle and/or personal injury.

6. Determine an appropriate position near the vehicle harness to attach the grounding screw. Clean away any dirt, debris or undercoating and drill a 3/32" hole.
7. Attach the T-Connectors white wire with the ring terminal to the vehicle using #10 screw provided.
8. Secure any loose wires using cable ties (provided).
9. Restore the jack into its original position and replace the trim panel and tread plates. Taking care not to pinch or damage any wires. The T-Connectors 4-flat trailer connector can be routed under the trim panel or retained inside the jack storage area when not in use.