


# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Toyota	Hilux (Mexican vehicle)
Toyota	T-100
Toyota	Tacoma

## CUSTOM WIRING HARNESS



## WIRING LOCATION GUIDE

### PICKUP TRUCKS (T)

Representative vehicle shown below

**T1** - Behind driver side taillight housing

**T2** - Behind passenger side taillight housing

**T3** - Behind driver side rear bumper

**T5** - Behind passenger side rear bumper



## NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

10mm socket

Ratchet

## ⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side

Tail / Running Circuits - 7.5 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

## Step 2 - Toyota Tacoma

Open the vehicle tailgate. Remove the 10mm screws holding the vehicle taillights in place and remove the taillights (A).

## Step 2 - Toyota T-100

The wiring harness will have connection points on the driver and passenger side of the frame.

## Step 3

The connectors will be similar to those on the T-connector harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs (B).

## Step 4

Insert the custom wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place (C).

## Step 5 - Toyota Tacoma

Route the custom wiring harness end with the green wire to the passenger side out through the hole between the vehicle bumper and body (D). Repeat step 4 on the passenger side using the harness end with the green wire.

## Step 5 - Toyota T-100

Route the custom wiring harness end with the green wire to the passenger side. Repeat step 4 on the passenger side using the harness end with the green wire.

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 6

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

## Step 7

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape (E).

## Step 8

Reinstall all items removed during install and reconnect negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

