

56113

BUICK REGAL
BUICK ALLURE

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.


¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

7/26/2010



English

1. Open the trunk and remove the rear scuff panel by pulling up (A). Remove plastic fasteners holding the felt trunk liner in place. Behind the trunk liner remove the plastic wing nuts holding the taillights in place(B). Remove the taillights.

2. On the drivers side locate the T-connectors taillight wiring harness (C). The harness will have connectors similar to those on the T-connector. Separate the connectors being sure not to damage the locking tabs (D). Remove grommet that the wires come out of from the inside of the vehicle. Make a small slit from the outside to the center of the grommet. Route the T-connector end with the yellow wires out of the slit made in the grommet. Insert the T-connector end between the seperated connectors make sure the connectors are fully inserted with locking tabs in place (E).

3. Route the T-connector end with the green wire to the passenger side behind the removed scuff panel. Repeat Step 2 on the passenger side using the T-Connector end with the green wire.

WARNING!
Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using eyelet and screw provided.

5. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the trunk.



56113