


C-606

DOUBLE LOCK GOOSENECK INSTALL TOOL

4/20/2021

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	CM-C606-MBWA	MAIN BODY WELDMENT ASSEMBLY
2	1	CM-C606-SWA	STRAP WELDMENT ASSEMBLY
3	2	CM-C606-SP	.188" SIDE PLATE
4	2	10-10606	HEX BOLT TAP BOLT
5	2	10-10071	HHCS, 1/2-13 UNC, 1-1/4, GRD5
6	3	20-00016	NUT, NYL LOCK, 1/2-13 UNC, GRD5



HITCH WEIGHT: 13 LBS.
INSTALL TIME: 5 MINUTES
INSTALL NOTES:

- NO ADDITIONAL DRILLING REQUIRED
- GOOSENECK SOLD SEPERATELY

INSTALLATION STEPS

- 1) Assemble the unit as shown above. Install items 5 & 6, tighten securely. Install items 4 & 2, tighten until threads are flush with the bottom of the nut.
 - 2) Place assembled unit in the bed of the truck with the strap through the 4" hole already cut in the bed.
 - 3) From beneath the truck, raise the gooseneck unit so the strap goes into the cylinder. Install items 4 & 6 into the top hole, holding the gooseneck unit in place with the C-606.
- * From inside the truck bed, use a 3/4" wrench or socket to raise the gooseneck securely into position.
- 4) Once the gooseneck is installed to the subkit crossarms, remove items 4 & 6 from the gooseneck cylinder and remove unit from the bed of the truck.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.